NOTES:
- *Make sure that the speaker cords are connected to the terminals securely. Insecure connections may cause not only sound to be interrupted and noise to be generated but also the cords to be shorted and the amplifier to break down.*
- *When listening to a stereo performance with the speaker system connected to a stereo amplifier, you will find that the bass is insufficient, the sound is not spread out and there is no stereo effect if the cords of one of the speaker systems have been plugged into the wrong polarity terminals.*
- *This speaker system does not include speaker cords. Purchase speaker cords of the neccessary length from your electrical appliance dealer.*

CABINET MAINTENANCE

- Use a polishing cloth or dry cloth to wipe off dust and dirt.
- When the cabinet is very dirty, wipe with a soft cloth dipped in some neutral cleanser diluted five or six times with water, and then wipe again with a dry cloth. Do not use furniture wax or cleaners.
- Never use thinners, benzine, insecticide sprays and other chemicals on or near the cabinets, since these will corrode the surfaces.

SPECIFICATIONS

Enclosure .... Book-shelf style, Air suspension type
System .... 2-way 2-speaker system
Loudspeakers:
   Woofer .... 25 cm (10 in) cone type
   Tweeter .... 6.6 cm (2-5/8 in) cone type
Nominal Impedance .... 6.0 ohms
Frequency Range .... 55 — 20,000 Hz
Sensitivity .... 90 dB/W at 1 m distance
Maximum Music Power .... 50 W
Rated Power .... 17 W
Crossover Frequency .... 5,500 Hz
External Dimensions .... 330(W) × 570(H) × 198(D) mm
                 13(W) × 22-7/16(H) × 7-13/16(D) in
Weight .... 6.5 kg (14 lb 5 oz)
Accessory Parts .... Operating Guide x1

NOTE:
Specifications and design subject to possible modification without notice, due to improvements.

FREQUENCY RESPONSE AND HARMONIC DISTORTION

IMPEDANCE

[183695]